


Floor Selection Panel



Operation

1. CTR16 will energize the relays to N/O as the default position. This will disconnect floor selection button from the left controller.
2. When a valid card is inserted into the reader, the corresponding relay representing floors that the person can enter is triggered to the N/C position. Thus, allowing the passengers to use the floor selection buttons. The relays contact will return to N/O position after maximum of 15 seconds which can be programmed.