Floor relay

Floor relay controller

Elevator controller

Lift motor room

Elevator motor

END

Decoder

Cable from every unit to the lift motor room

Level 25

Unit intercom hand set with elevator release button

Level 24

Cable for intercom from every unit to every floor
Down to the visitor call panel next to the elevator

Level 2

Power supply

Intercom Visitor call panel

Power supply

Elevator

Level 1

Before implementation of Securitex Tele-elevator-controller (E-levatex-8)