


Securitex Tele-Elevator-control system

E-levatex-8



Operation of the Elevator Telephony system

- Visitor call owner from the Telephony system by entering the 4 digit resident code.
- Resident Telephone or mobile phone ring
- Resident pick up the phone and communicate with the visitor.
- To allow entry to the lift lobby only resident press "0" on phone keypad
- To allow entry to the lift lobby and the resident exclusive floor via elevator, resident enter 4 digits security password on the telephone keypad.
- To denied entry, resident just hang-up the phone.

Optional monitor

- To view visitor at lift lobby, resident activate the wireless monitor in the unit.

Optional Security

- DVR recorder install in main management office record the visitor using the telephony system and also record the movement around the premises

Note: The telephony system can be either Enterphone or Trigon system.

To know more about this system please contact us at:

Securitex Electronic Systems Engineering

Block 9010 Tampines St 93 #04-145 Singapore 528844 Tel: 65-67852171 Fax: 65-67863351

Email: davidtan@securitex.com.sg