



Mounting the Camera and Lens Assembly

The Mitre housing is fitted with an adjustable/removable camera mounting plate. This is held in place by two stainless steel brackets (one at each side.) To remove the camera mounting plate, unscrew both M4 screws on one of the brackets and loosen the screws on the other bracket. This enables the camera mounting plate to be removed and the camera and lens assembly to be fitted. (See diagram below for details)



The Camera plate itself also has a four slots to accommodate different camera/ lens combinations. All of these slots are 6.5mm wide, 25mm long. The spacings are shown on page 4



Safety Precautions

All persons installing and maintaining this equipment should be suitably qualified and work to national and local standards and codes of practice

The equipment is subject to remote control and may be operated at any time. Persons working on the equipment should take appropriate precautions to ensure that any unexpected movement does not occur as this could lead to injury.

In locations or areas where the risk of Injury occurs, or any part of the assembly may become detached or fall for any reason, a strong safety chain or wire hawser should be attached between the equipment and the mounting surface. At all times, normal safety precautions must be employed.

Hazardous voltages are present in this equipment and may also be present in any associated items.

All fixings and fastenings must be thoroughly checked for tightness one month following installation, and thereafter at regular 6 monthly intervals.